

Late Start 1,2 & 4P

Adulting is hard, setting up your Late Start tent is EASY!



Late Start 2 shown

In order to familiarize yourself with your new tent, we recommend you "test pitch" before your first adventure. For additional information please visit www.kelty.com.

Package Includes: Tent carry bag, tent body, tent fly, two tent poles, guyline cords, and tent stakes.

1



On an even piece of ground lay out tent body and stake corners. Assemble poles, making sure all pole sections are fully connected at joints. Lay poles on top of tent body in an X pattern.
Pro Tip: Do not shake poles out during assembly, take care of your gear and it will take care of you!

2



Insert poles tip into "Quick Corner" fabric sleeve, flex pole and insert the pole tip into opposite Quick Corner. Then repeat for the second pole.
Tip: Please ensure each pole is fully seated within each Quick Corner sleeve.



"Quick Corner" fabric sleeves



Pole Clip



Hook & loop fly pole wrap



Fly Attachment

3



Start in the center, gently lift up tent body and attach center clip where the poles cross
Tip: center clip attaches to the pole that is on top. Then follow each pole down and connect all clips to poles.

4



Drrape tent fly over tent body. Please match colored webbing for correct rain fly and tent body orientation. Attach hook & loop on underside of fly (at guy out points) to poles. Attach rainfly buckles to tent body buckles at each stake loop. Stake out vestibule and all guylines.